



TALARIA TAIL TIDY SET-UP GUIDE

PROVIDED BY
UrbanMoto
Distribution >>>

- TOOLS REQUIRED**
- 3, 4 & 5 MM ALLEN KEY
 - 10MM & 15MM SPANNER
 - PH2 SCREWDRIVER
 - 5 CABLE TIES

* FOR OFF ROAD USE, WE RECCOMEND THE USE OF A FLEXIBLE ENURO STYLE PLATE *
* SUPPLIED BY: <https://www.flexiplates.co.uk/> *



- DISCONNECT & REMOVE THE BATTERY
- EXPOSE REAR LIGHT CLUSTER SHROUD
- DISCONNECT ALL 5 CONNECTORS
- * PLEASE NOTE ORANGE WIRE IS FOR LH INDICATOR AND BLUE WIRE IS FOR RH *



- REMOVE 2 X 5MM ALLEN BOLTS FROM EITHER SIDE OF THE SUBFRAME
- REMOVE 4MM ALLEN BOLTS FROM EITHER SIDE OF BATTERY COVER RELEASE
- * THE SUBFRAME IS NOW FREE TO REMOVE *



- REMOVE 5 X 4MM ALLEN BOLTS FROM UNDERTRAY
- REMOVE 4 X PH2 SCREWS FROM UNDERTRAY
- REMOVE UNDERTRAY
- REMOVE 4 X 10MM NUTS
- REMOVE SUBFRAME FROM TAIL UNIT



- REMOVE 15MM NUTS FROM INDICATORS
- REMOVE INDICATORS
- REMOVE 10MM NUTS FROM BRAKE LIGHT
- REMOVE BRAKE LIGHT



- INSTALL BRAKE LIGHT
- INSTALL INDICATORS
- * ENSURE THE LH AND RH INDICATORS ARE FIXED TO THE MOUNT ACCORDINGLY AND THAT THE CLEAR PLASTIC SECTION OF THE BRAKE LIGHT IS FACING THE NUMBER PLATE *



- INSTALL TAIL TIDY TO SUBFRAME USING 2 X 10MM NUTS
- ENSURE TAIL TIDY IS SAT LEVEL WITH THE SEAT AND FAIRING
- USE THE 5 X CABLE TIES TO RUN THE WIRING TO THE FRONT OF THE SUBFRAME, EXPOSING ON THE LH SIDE
- * YOU MAY NEED TO REMOVE THE SEAT UNDERTRAY IN ORDER TO ALLOW THE WIRES TO TUCK.
- IF THE TAIL TIDY HANGS LOW, SLIGHT BENDING OF THE LOWER SECTION OF THE BRACKET MAY BE REQUIRED *



FINAL PRODUCT